



# PP-RCT Pipes & Fittings Chemical Resistance





Teel BQ PP-RCT pipes have a high resistance to various acids and chlorides due to the chemical properties of polypropylene. As such, Teel BQ Americas PP-RCT pipe is highly suitable for the transportation of hard, soft or potable water with consumable amounts of chlorine, acidic fluids, DI water or Industrial chemicals. The following table contains an evaluation of the chemical resistance to a number of fluids judged to be either aggressive or not towards polypropylene. This evaluation is based on values obtained by immersion of polypropylene test specimens in the fluid concerned at 68°, 140° and 212°F and atmospheric pressure, followed in certain cases by the tensile characteristics. The following chart provides a general chemical resistance of Teel BQ PP-RCT pipe and fittings.

## Definitions, Symbols and Abbreviations

The criteria of classifications, definitions, symbols and abbreviations adopted in this document are as follows:

### **S = Satisfactory**

The chemical resistance of polypropylene exposed to the action of a fluid is classified as “satisfactory” when the results of test are acknowledged to be “satisfactory” by the majority of the participants in the evaluation.

### **L = Limited**

The chemical resistance of polypropylene exposed to the action of fluid is classified as “limited” when the results of tests are acknowledged to be “limited” by the majority of the participants in the evaluation. Also classified as “limited” are the resistances to the action of chemical fluids for which judgements “S” and “NS” or “L” are pronounced to an equal extent.

### **NS = Not satisfactory**

The chemical resistance of polypropylene exposed to the action of a fluid classified as “not satisfactory” when the results of test are acknowledged to be “not satisfactory” by the majority of the participants in the evaluation. Also classified as “not satisfactory” are materials for which judgement “L” and “NS” are pronounced to an equal extent.

**Sat.sol** Saturated aqueous solution, prepared at 68°F

**Sol** Aqueous solution at a concentration higher than 10% but not saturated

**Dil.sol** Dilute aqueous solution at a concentration equal to or lower than 10%

**Work.sol** Aqueous solution having the usual concentration for industrial use

Solution concentrations reported in the text are expressed as a percentage by mass. The aqueous solutions of sparingly soluble chemicals are considered, as far as chemical action towards polypropylene is concerned, as saturated solutions.

# PP-RCT Pipes & Fittings Chemical Resistance



In general, common chemical names are used in this document.

The table is made as a first guideline for users of polypropylene. If a chemical compound is not found or if there is an uncertainty on the chemical resistance in an application, please contact Teel BQ Americas.

S = Satisfactory • L = Limited • NS = Non-Satisfactory

Reagent	Concentration	68°F	140°F	212°F
Acetic acid	Up to 40 %	S	S	-
Acetic acid	50 %	S	S	L
Acetic acid, glacial	> 96 %	S	L	NS
Acetic anhydride	100 %	S	-	-
Acetone	100 %	S	S	-
Aceprophenone	100 %	S	L	-
Acrylonitrile	100 %	S	-	-
Air		S	S	S
Allyl alcohol	100 %	S	S	-
Almond oil		S	-	-
Alum	Sol	S	S	-
Ammonia, aqueous	Sat.sol	S	S	-
Ammonia, dry gas	100 %	S	-	-
Ammonia, liquid	100 %	S	-	-
Ammonium acetate	Sat. sol	S	S	-
Ammonium chloride	Sat.sol	S	S	-
Ammonium fluoride	Up to 20 %	S	S	-
Ammonium hydrogen carbonate	Sat.sol	S	S	-
Ammonium metaphosphate	Sat.sol	S	S	S
Ammonium nitrate	Sat.sol	S	S	S
Ammonium persulphate	Sat.sol	S	S	-
Ammonium phosphate	Sat.sol	S	-	-
Ammonium sulphate	Sat.sol	S	S	S
Ammonium sulphide	Sat.sol	S	S	-
Amyl acetate	100 %	L	-	-
Amyl alcohol	100 %	S	S	S
Aniline	100 %	S	S	-

S = Satisfactory • L = Limited • NS = Non-Satisfactory

Reagent	Concentration	68°F	140°F	212°F
Apple juice		S	-	-
Aqua regia	HCl/HNO <sub>3</sub> =3/1	NS	NS	NS
Barium bromide	Sat.sol	S	S	S
Barium carbonate	Sat.sol	S	S	S
Barium chloride	Sat.sol	S	S	-
Barium hydroxide	Sat.sol	S	S	S
Barium sulphide	Sat.sol	S	S	S
Beer		S	S	-
Benzene	100 %	L	NS	NS
Benzoic acid	Sat.sol	S	S	-
Benzyl alcohol	100 %	S	L	-
Borax	Sol	S	S	-
Boric acid	Sat.sol	S	-	-
Boron trifluoride	Sat.sol	S	-	-
Bormine, gas		NS	NS	NS
Bromine, liquid	100 %	NS	NS	NS
Butane, gas	100 %	S	-	-
Butanol	100 %	S	L	L
Butyl acetate	100 %	L	NS	NS
Butyl glycol	100 %	S	-	-
Butyl phenols	Sat.sol	S	-	-
Butyl phthalate	100 %	S	L	L
Calcium carbonate	Sat.sol	S	S	S
Calcium chlorate	Sat.sol	S	S	-
Calcium chloride	Sat.sol	S	S	-
Calcium hydroxide	Sat.sol	S	S	S
Calcium hypochlorite	Sol	S	-	-
Calcium nitrate	Sat.sol	S	S	-
Camphor oil		NS	NS	NS
Carbon dioxide, dry gas		S	S	-
Carbon dioxide, wet gas		S	S	-

# PP-RCT Pipes & Fittings Chemical Resistance



S = Satisfactory • L = Limited • NS = Non-Satisfactory

Reagent	Concentration	68°F	140°F	212°F
Carbon disulphide	100 %	S	NS	NS
Carbon monoxide, gas		S	S	-
Carbon tetrachloride	100 %	NS	NS	NS
Castor oil	100 %	S	S	-
Caustic soda	Up to 50 %	S	L	L
Chlorine, aqueous	Sat.sol	S	L	-
Chlorine, dry gas	100 %	NS	NS	NS
Chlorine, liquid	100 %	NS	NS	NS
Chloroacetic acid	Sol	S	-	-
Chloroethanol	100 %	S	-	-
Chloroform	100 %	L	NS	NS
Chlorosulphonic acid	100 %	NS	NS	NS
Chrome alum	Sol	S	S	-
Chromic acid	Up to 40 %	S	L	NS
Citric acid	Sat.sol	S	S	S
Coconut oil		S	-	-
Copper (II) chloride	Sat.sol	S	S	-
Copper (II) nitrate	Sat.sol	S	S	S
Copper (II)	Sat.sol	S	S	-
Corn oil		S	L	-
Cottonseed oil		S	S	-
Cresol	Greater than 90 %	S	-	-
Cyclohexane	100 %	S	-	-
Cyclohexanol	100 %	S	L	-
Cyclohexanone	100 %	L	NS	NS
Decalin (decahydronaphthalene)	100 %	NS	NS	NS
Dextrin	Sol	S	S	-
Dextrose	Sol	S	S	S
Dibutyl phthalate	100 %	S	L	NS
Dichloroacetic acid	100 %	L	-	-
Dichloroethylene (A and B)	100 %	L	-	-

S = Satisfactory • L = Limited • NS = Non-Satisfactory

Reagent	Concentration	68°F	140°F	212°F
Diethanolamine	100 %	S	-	-
Diethyl ether	100 %	S	L	-
Diethylene glycol	100 %	S	S	-
Diglycolic acid	Sat.sol	S	-	-
Diisooctyl	100 %	S	L	-
Dimethyl amine, gas		S	-	-
Dimethyl formamide	100 %	S	S	-
Dioctyl phthalate	100 %	L	L	-
Dioxane	100 %	L	L	-
Distilled water	100 %	S	S	S
Ethanolamine	100 %	S	-	-
Ethyl acetate	100%	L	NS	NS
Ethyl alcohol	Up to 95 %	S	S	S
Ethyl chloride, gas		NS	NS	NS
Ethylene chloride (mono and di)		L	L	-
Ethyl ether	100 %	S	L	-
Ethylene glycol	100 %	S	S	S
Ferric chloride	Sat.sol	S	S	-
Formaldehyde	40 %	S	-	-
Formic acid	10 %	S	S	L
Formic acid	85 %	S	NS	NS
Formic acid, anhydrous	100 %	S	L	L
Fructose	Sol	S	S	S
Fruit juice		S	S	S
Gasoline, petrol (aliphatic hydrocarbons)		NS	NS	NS
Gelatine		S	S	-
Glucose	20 %	S	S	S
Glycerine	100 %	S	S	S
Glycolic acid	30 %	S	-	-
Heptane	100 %	L	NS	NS
Hexane	100 %	S	L	-

# PP-RCT Pipes & Fittings Chemical Resistance



S = Satisfactory • L = Limited • NS = Non-Satisfactory

Reagent	Concentration	68°F	140°F	212°F
Hydrobromic acid	Up to 48 %	S	L	NS
Hydrochloric acid	Up to 20 %	S	S	S
Hydrochloric acid	30 %	S	L	L
Hydrochloric acid	From 35 to 36 %	S	-	-
Hydrofluoric acid	Dil.sol	S	-	-
Hydrofluoric acid	40 %	S	-	-
Hydrogen	100 %	S	-	-
Hydrogen chloride, dry gas	100 %	S	S	-
Hydrogen peroxide	Up to 10 %	S	-	-
Hydrogen peroxide	Up to 30 %	S	L	-
Hydrogen sulphide, dry gas	100 %	S	S	-
Iodine, in alcohol		S	-	-
Isoctane	100 %	L	NS	NS
Isopropyl alcohol	100 %	S	S	S
Isopropyl ether	100 %	L	-	-
Lactic acid	Up to 90 %-	S	S	-
Lanoline		S	L	-
Linseed oil		S	S	S
Magnesium carbonate	Sat.sol	S	S	S
Magnesium chloride	Sat.sol	S	S	-
Magnesium hydroxide	Sat.sol	S	S	-
Magnesium sulphate	Sat.sol	S	S	-
Maleic acid	Sat.sol	S	S	-
Mercury (II) chloride	Sat.sol	S	S	-
Mercury (II) cyanide	Sat.sol	S	S	-
Mercury (I) nitrate	Sol	S	S	-
Mercury	100 %	S	S	-
Methyl acetate	100 %	S	S	-
Methyl alcohol	5 %	S	L	L
Methyl amine	Up to 32 %	S	-	-
Methyl bromide	100 %	NS	NS	NS

S = Satisfactory • L = Limited • NS = Non-Satisfactory

Reagent	Concentration	68°F	140°F	212°F
Methyl ethyl ketone	100 %	S	-	-
Methylene chloride	100 %	L	NS	NS
Milk		S	S	S
Monochloroacetic acid	>85 %	S	S	-
Naphtha		S	NS	NS
Nickel chloride	Sat.sol	S	S	-
Nickel nitrate	Sat.sol	S	S	-
Nickel sulphate	Sat.sol	S	S	-
Nitric acid	Up to 30 %	S	NS	NS
Nitric acid	From 40 to 50 %	L	NS	NS
Nitric acid, fuming (with nitrogen dioxide)		NS	NS	NS
Nitrobenzene	100%	S	L	-
Oleic acid	100%	S	L	-
Oleum (sulphuric acid with 60 % of SO <sub>3</sub> )		S	L	-
Olive oil		S	S	L
Oxalic acid	Sat.sol	S	L	NS
Oxygen, gas		S	-	-
Paraffin oil (FL65)		S	L	NS
Peanut oil		S	S	-
Peppermint oil		S	-	-
Perchloric acid	(2 N) 20 %	S	-	-
Petroleum ether (ligroine)		L	L	-
Phenol	5 %	S	S	-
Phenol	90 %	S	-	-
Phosphine, gas		S	S	-
Phosphoric acid	Up.to 85 %	S	S	S
Phosphorus oxychloride	100 %	L	-	-
Picric acid	Sat.sol	S	-	-
Potassium bicarbonate	Sat.sol	S	S	S
Potassium borate	Sat.sol	S	S	-
Potassium bromate	Up to 10 %	S	S	-



# PP-RCT Pipes & Fittings Chemical Resistance



S = Satisfactory • L = Limited • NS = Non-Satisfactory

Reagent	Concentration	68°F	140°F	212°F
Potassium bromide	Sat.sol	S	S	-
Potassium carbonate	Sat.sol	S	S	-
Potassium chlorate	Sat.sol	S	S	-
Potassium chlorite	Sat.sol	S	S	-
Potassium chromate	Sat.sol	S	S	-
Potassium cyanide	Sol	S	-	-
Potassium dichromate	Sat.sol	S	S	S
Potassium ferricyanide	Sat.sol	S	S	-
Potassium fluoride	Sat.sol	S	S	-
Potassium hydroxide	Up to 50 %	S	S	S
Potassium iodide	Sat.sol	S	-	-
Potassium nitrate	Sat.sol	S	S	-
Potassium perchlorate	10 %	S	S	-
Potassium permanganate	(2 N) 30 %	S	-	-
Potassium persulphate	Sat.sol	S	S	-
Potassium sulphate	Sat.sol	S	S	-
Propane, gas	100 %	S	-	-
Propionic acid	>50 %	S	-	-
Pyridine	100 %	L	-	-
Seawater		S	S	S
Silicon oil		S	S	S
Silver nitrate	Sat.sol	S	S	L
Sodium acetate	Sat.sol	S	S	S
Sodium benzoate	35 %	S	L	-
Sodium bicarbonate	Sat.sol	S	S	S
Sodium carbonate	Up to 50 %	S	S	L
Sodium chlorate	Sat.sol	S	S	-
Sodium chloride	Sat.sol	S	S	-
Sodium chlorite	2 %	S	L	NS
Sodium chlorite	20 %	S	L	NS
Sodium dichromate	Sat.sol	S	S	S

S = Satisfactory • L = Limited • NS = Non-Satisfactory

Reagent	Concentration	68°F	140°F	212°F
Sodium hydrogen carbonate	Sat.sol	S	S	S
Sodium hydrogen sulphate	Sat.sol	S	S	-
Sodium hydrogen sulphite	Sat.sol	S	-	-
Sodium hydroxide	1 %	S	S	S
Sodium hydroxide	From 10 to 60 %	S	S	S
Sodium hypochlorite	5 %	S	S	-
Sodium hypochlorite	10 % - 15 %	S	-	-
Sodium hypochlorite	20 %	S	L	-
Sodium metaphosphate	Sol	S	-	-
Sodium nitrate	Sat.sol	S	S	-
Sodium perborate	Sat.sol	S	S	-
Sodium phosphate (neutral)		S	S	S
Sodium silicate	Sol	S	S	-
Sodium sulphate	Sat.sol	S	S	-
Sodium sulphide	Sat.sol	S	-	-
Sodium sulphite	40 %	S	S	S
Sodium thiosulphate (hypo)	Sat.sol	S	-	-
Soybean oil		S	L	-
Succinic acid	Sat.sol	S	S	-
Sulphuric acid	Up to 10 %	S	S	S
Sulphuric dioxide, dry or wet	100 %	S	S	-
Sulphur acid	From 10 to 30 %	S	S	-
Sulphuric acid	50 %	S	L	L
Sulphuric acid	96 %	S	L	NS
Sulphuric acid	98 %	L	NS	NS
Sulphurous acid	Up to 30 %	S	-	-
Tartaric acid	Sat.sol	S	S	-
Tetrahydrofuran	100 %	L	NS	NS
Tetralin	100 %	NS	NS	NS
Thiophene	100 %	S	L	-
Tin (IV) chloride	Sol	S	S	-

# PP-RCT Pipes & Fittings Chemical Resistance



S = Satisfactory • L = Limited • NS = Non-Satisfactory				
Reagent	Concentration	68°F	140°F	212°F
Tin (II) chloride	Sat.sol	S	S	-
Toluene	100 %	L	NS	NS
Trichloroacetic acid	Up to 50 %	S	S	-
Trichloroethylene	100 %	NS	NS	NS
Triethanolamine	Sol	S	-	-
Turpentine		NS	NS	NS
Urea	Sat.sol	S	S	-
Vinegar		S	S	-
Water, Brackish		S	S	S
Water, Deionized		S	S	S
Water, Distilled		S	S	S
Water, Drinkable		S	S	S
Water, Mineral		S	S	S
Water (sea water)		S	S	S
Whiskey		S	S	-
Wines		S	S	-
Xylene	100 %	NS	NS	NS
Yeast	Sol	S	S	S
Zinc chloride	Sat.sol	S	S	-
Zinc sulphate	Sat.sol	S	S	-

## Disclaimer:

The information contained herein is to our knowledge accurate and reliable as of the date of publication. Teel BQ Americas extends no warranties and makes no representations as to the accuracy or completeness of the information contained herein, and assumes no responsibility regarding the consequences of its use or for any printing errors.

Our products are intended for sale to industrial and commercial customers. It is the customer's responsibility to inspect and test our products in order to satisfy himself as to the suitability of the products for the customer's particular purpose. Insofar as products supplied by Teel BQ Americas or its subsidiary companies are used in conjunction with third party materials, it is the responsibility of the customer to obtain all necessary information relating to the third party materials and ensure that Teel BQ Americas products when used together with these materials are suitable for the customer's particular purpose.



1060 Teel Court

Baraboo, WI 53913

Phone: (608) 355-3080

Fax: (608) 355-3088

[www.TeelBQAmericas.com](http://www.TeelBQAmericas.com)